

Communication Ports

The Terminal Charger also has 2 communications ports: RS-232 (DB-9) and USB (Type II). The Terminal Charger uses a standard RS-232 (DB-9 Male – DB-9 Female) cable with a length of 3 Meters or less.



Both communication connectors on the back of the universal terminal charger are wired “straight through.” This means that the communications settings on the handheld terminal will determine the settings on the communication cradle. The Terminal Charger has no internal or external settings that can be changed.

The full-speed USB or RS-232 communication port can be used for uploading and downloading of data files to the handheld terminal. These ports can also be used to load a new or updated operating system into the hand-held terminal.

DB-9 Pin out (RS-232)

1 – DCD (Data Carrier Detect)	6 – DSR (Data Set Ready)
2 – RXD (Receive Data)	7 – RTS (Request To Send)
3 – TXD (Transmit Data)	8 – CTS (Clear To Send)
4 – DTR (Data Terminal Ready)	9 – NC (No Connection)
5 - GND (Signal Ground)	

Regulatory Information

All American Microsystems, Ltd. devices are designed to be compliant with rules and regulations in locations they are sold and will be labeled as required. Any changes or modifications to American Microsystems, Ltd. equipment, not expressly approved by American Microsystems, Ltd., could void the user's authority to operate the equipment.

Power Supply

Use only an American Microsystems, Ltd. approved Power Supply, output rated 5 VDC and minimum 2.8A. The Power Supply is certified to EN60950.

Disclaimer

American Microsystems, Ltd. reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult American Microsystems, Ltd. to determine whether any such changes have been made. The information in this publication does not represent a commitment on the part of American Microsystems, Ltd.

American Microsystems, Ltd. shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of American Microsystems, Ltd.

FCC Declaration of Conformity
Product Name: Terminal Charger
Model Number: ACC-5925

Radio Frequency Interference Requirements

This equipment complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This equipment may not cause harmful interference, and (2) this equipment must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential environment. This equipment generates uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If you determine the equipment does cause harmful interference to radio or television reception (this may be determined by monitoring the interference while turning the equipment off and on), you are encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or TV technician for help.

Radio Frequency Interference Requirements - Canada

This Class A digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

Marking and European Economic Area (EEA)

CE Products intended for sale within the European Union are marked with the CE mark which indicates compliance to applicable Directives and European Normes (EN), as follows. Amendments to these Directives or EN's are included.

- Electromagnetic Compatibility Directive 89/336/EEC
- Low Voltage Directive 73/23/EEC



Terminal Charger



User's Guide

Introduction

The ACC-5925 Terminal Charger charges any AML M7220, M71V2 or M5900 Series handheld terminal, along with one spare battery.

About This Guide

This guide provides instruction on setting up and using the ACC-5925 Terminal Charger.

Set Up

Setting up the cradle includes unpacking, connecting the power cable and mounting the cradle on a table top.

Unpacking the Cradle

The shipping box includes the following:

- One ACC-5925 Terminal Charger
- One PWR-7100 Power Supply (120VAC) or PWR-7150 (220VAC)
- One Line Cord with PWR-7150
- This User's Guide.

If any parts are missing or damaged, contact your authorized Customer Support Representative immediately. Save the shipping box for storing or shipping.

Connecting the Power

The PWR-7100 power supply is included with the ACC-5925 Terminal Charger for 120VAC. The PWR-7150 power supply is included with the ACC-5925 Terminal Charger for 220VAC, along with a country specific line cord.

Use only an American Microsystems, Ltd. approved power supply rated at 5 VDC at a minimum of 2.8 Amps. The power supply connects to the ACC-5925 by a 2.1mm x 5.5mm, barrel center-positive connector.

To connect power to the cradle:

1. Plug-in the Power Supply to a standard AC electrical outlet.
2. Connect the Power Supply Plug to the barrel power jack on the cradle.
3. The cradle LED's will turn green to indicate that power is available.
4. The LED's remain green until a terminal or battery is inserted into the slots.

Charging

For wireless handhelds, turn the terminal off and insert it into a cradle slot. It begins to charge as soon as it is inserted. To properly charge the battery, be sure the terminal is off.

Batch collection devices, including the M5900 series terminals, should be charged while powered on. These units will automatically power on if inserted into the ACC-5925 when in off or suspended modes.

Indicator Lights

LED Color	Description
Off	No power supplied to terminal charger.
Green	If no terminal is present in the charger, green indicates that there is power available. If terminal is present, green indicates that the terminal is fully charged.
Red	Terminal or battery is present in the terminal charger and the battery is being charged.

Troubleshooting




Symptom	Cause	Suggested Action
LED does not light when the terminal charger is powered on.	Terminal charger is not receiving power.	Make sure the power supply is securely connected and receiving power.
LED stays green when the terminal is inserted.	Terminal is not seated firmly in the terminal charger, or the battery is not properly installed in the terminal.	Make sure the battery is properly installed in the terminal, and reseal the terminal in the terminal charger.
	Battery is charged.	Normal status.
LED stays red for more than 6 hours.	Battery faulty and can not be charged.	Replace battery with an AML approved battery.

The Terminal Charger

The cradle automatically charges the terminal battery while it is resting in the cradle. The cradle also includes an extra slot to charge a spare battery. The Terminal Charger can accommodate the terminal with or without the optional pistol grip handle.



The Terminal Charger has three indicator lights:

-  - Indicates that the terminal charger is plugged in.
-  - Indicates the terminal main battery is charging.
-  - Indicates the spare battery is charging.

When the battery charging LED is red, the battery is charging. When the battery charge LED is green, the battery is fully charged. A fully discharged battery takes about 6 hours to completely recharge.